



INSTALLATION INSTRUCTIONS

APFDR 2" Shower Drain Installation



Customer Support: 1.877.947.7769
Email: apsupport@accessibilitypro.com

APFDR 2" Shower Drain Installation Instructions

Step 1) Apply silicone caulk between the drain flange and the inside surface of the shower around the drain hole to provide a water tight seal.

Step 2) On the underside of the shower, install the rubber washer, then the fiber washer over the threaded part of the drain body.

Step 3) Thread on the locknut and hand tighten, then snug the locknut with a wrench. Do not overtighten. Wipe away excess caulking from the inside surface, near the fitting.

Step 4) Slide rubber caulking gasket into the drain body and slip over pipe.

IMPORTANT: Make certain that the beveled end of the gasket is facing up and is flush with the top of the pipe.

Step 5) Using a large screwdriver and the tool provided with the drain, tighten the inside caulking nut into the drain body.

WARNING: do not overtighten caulking or locknuts on any plastic drain.

Do not use an oil based sealer. This may cause the drain to break or warp. Use on ASTM recommended silicone sealer.

Step 6) Finish the installation by snapping the strainer into place.

NOTE: Watertight installation of the drain is the installer's responsibility. Drain leakage is excluded from the limited warranty.

