



www.freedomshowers.com

INSTALLATION INSTRUCTIONS FOR GRAB BARS

Recommended tools for installation:

1/4" Power Drill

1/8" drill bit when drilling through fiberglass

#2 Phillips Screw Driver and/or Phillips drill insert

1/2" Open end wrench or a small Crescent wrench

Tape measure

Pencil/pen

Center Punch

Silicone Caulk

Screws appropriate to the installation surface

7. Take the remaining #10x2" screws and place them into the remaining open holes. Use care to snug up the screws, but do not over-torque so that the screws strip in the backing material.

8. Use a power drill with a Phillips drill bit to fully install these mounting screws.

9. If installing a bar with snap-on covers, move the covers into place at each flange. Twist the covers clockwise or counter clockwise to tighten the covers onto the flanges.

THIS COMPLETES THE INSTALLATION OF THE GRAB BAR

1. Wood reinforcements must be solidly installed behind the tile wall surface to provide a secure mounting surface to attach the grab bars. Grab bars must be installed at these locations only.

2. For grab bars with concealed flange, use the handle of a Phillips screw driver to tap back the covers on the bottom edge of the flange covers. It will be convenient in the installation process if the covers are tapped together in the center of the grab bar.

3. Determine the position you want to install the bar. Place the bar against the wall. Using a pencil, mark the location of each mounting hole at both ends of the bar.

4. Using a power drill with a 1/4" diameter carbide tipped drill bit, drill each mounting hole.

5. Apply silicone caulking around and inside each drilled hole before installing the grab bar.

6. Take two (20 of the #10x2" Stainless Steel screws. By hand, screw in. Hand tighten mounting screw in each end of the bar into the wall.